





# **GATOR BLOCK BOND XP**

## **XTRA PERFORMANCE POLYURETHANE ADHESIVE** FASTEST SETTING GLUE IN THE INDUSTRY!

ASTEST SETTING GLUE IN THE INDUSTR

# **IDEAL FOR**

- Overlays and pool copings
- Steps and wall caps
- Fire pits (up to 204°C)
- Retaining walls
- Masonry
- Natural or wet cast stones
- Concrete pavers and Clay pavers
- Dry and damp surfaces

# FEATURES

- Xtra fast cure time
- Xtra bond strength
- Xtra durability
- Set Time: Up to 1 hour
- Permanent Bond in 24 hours
- VOC compliant
- Low odor
- High performance
- Non-shrinking does not crack or lose bond
- Prise Rapide
- Works above 0°C



# AllianceGator.com/europe/

# **GATOR BLOCK BOND XP ADHESIVE**

GATOR BLOCK BOND XP LOW VOC, is one of the strongest polyurethane adhesives on the market. It is specially formulated for overlays, pool copings, steps and wall caps, concrete pavers, wet cast, natural stones, retaining walls, masonry units and bricks. GATOR BLOCK BOND XP can be used on dry or damp surfaces. Drying time varies depending on factors such as: humidity, porosity, temperature and materials bonded together.

# **APPLICATION INSTRUCTIONS :**

Application instructions for GATOR BLOCK BOND XP LOW VOC polyurethane adhesive.

To ensure optimal adhesion, make sure that surfaces are clean and free of any foreign matter. Cure time varies with temperature, humidity, and the porosity of the materials joined.

#### **PLEASE NOTE**

- Wear gloves during application of adhesive; once cured, material cannot be removed.
- Not intended for applications with continuous submersion.
- If adhesion to a substrate is questionable, a test application must be conducted.
- To ensure optimal adhesion, make sure that the concrete or stone surfaces are clean and free of any foreign matter.
- Material may be repositioned for up to 30 minutes without losing bond strength. Moisture will shorten the open time of polyurethane adhesives. Avoid use when raining or onto standing water.
- GATOR BLOCK BOND XP LOW VOC polyurethane adhesive forms a tenacious bond overnight.
- Cure time varies with temperature, humidity, and the porosity of the materials joined.
- Clean all tools and equipment immediately after use with mineral solvent or an equivalence.
- Cured material must be mechanically removed.
- 1. Always refer to the latest GATOR BLOCK BOND XP LOW VOC Technical Data Sheet (TDS) at AllianceGator.com before installing GATOR BLOCK BOND XP LOW VOC. Make sure that the surfaces you are bonding together are clean.
- 2. Cut the spout and puncture a hole in the cartridge with a nail.
- 3. Using a caulking gun, apply GATOR BLOCK BOND XP LOW VOC polyurethane adhesive on the clean surfaces.
- 4. Join the two surfaces firmly, use twisting motion.



### **COVERAGE FOR 6MM BEAD (APPROX.)**

296 ml

~ 9 m

FOR MORE DETAILS, VISIT

AllianceGator.com/europe/