

GATOR BASE SCREWS

TDS Revision Date (dd/mm/yyyy): 29/04/2025

TECHNICAL DATA SHEET


Update: April 29, 2025
Make sure you have an updated technical data sheet on hand.
Canada and U.S. dial **1-855-847-7767** or (450) 624-1611

Description: Fastening [Gator Edge](#) with the **GATOR BASE SCREW** through the [Gator Base](#) reinforces the outside perimeter, creating a strong lateral support. **GATOR BASE SCREWS** are a required component on any [Gator Base](#) install.

- Features:**
- Use with all [Gator Base](#) installation
 - Use with all the Gator Edges: [Rigid and Flex](#), [Mini](#) and [Tile](#)
 - Reinforces the outside perimeter
 - Creates a strong lateral support
 - Locking all components into one
 - Use **GATOR BASE SCREWS** to fasten [Gator Edge](#) to [Gator Base](#)

For use on: Use **GATOR BASE SCREWS** to fasten [Gator Edge](#) to [Gator Base](#). Locks all components into one

Installation instructions:



- STEP 1** It can be screwed either before or after the paving installation.
- STEP 2** Ensure [Gator Edges](#) are installed firmly against the paving units.
The [Gator Base](#) must be 6" (15 cm) wider on all sides than the paved area.
- STEP 3** When using **GATOR BASE SCREWS**, install one screw at every second hole and every junction of the edges to ensure continuous lateral support.



Packaging:	Product	Units per Package	Package per Box
	Gator Base Screws	1/8 LD HOLLOW ANCHOR (50 UNITS)	20



Alliance Designer Products Inc.
 1800 Berlier st., suite 200, Laval, Quebec, Canada H7L 4S4
 Tel.: 450 624-1611 Fax : 450 624-1622 Toll free : 1 866-212-1611
 www.alliancegator.com - Email : info@alliancegator.com