



**GATOR BASE SCREWS**

TDS Revision Date (dd/mm/yyyy): 07/10/2021

# TECHNICAL DATA SHEET


**Update:** October 7, 2021  
Make sure you have an updated technical data sheet on hand.  
Canada and U.S. dial **1-855-847-7767** or (450) 624-1611

**Description:** Fastening [Gator Edge](#) with the **GATOR BASE SCREW** through the [Gator Base](#) reinforces the outside perimeter, creating a strong lateral support. **GATOR BASE SCREWS** are a required component on any [Gator Base](#) install.

- Features:**
- Use with all [Gator Base](#) installation
  - Use with all the Gator Edges: [Rigid and Flex](#), [Mini](#) and [Tile](#)
  - Reinforces the outside perimeter
  - Creates a strong lateral support
  - Locking all components into one
  - Use **GATOR BASE SCREWS** to fasten [Gator Edge](#) to [Gator Base](#)

**For use on:** Use **GATOR BASE SCREWS** to fasten [Gator Edge](#) to [Gator Base](#). Locks all components into one

**Installation instructions:**



- STEP 1 It can be screwed either before or after the paver installation.
- STEP 2 Ensure [Gator Edges](#) are installed firmly against the pavers. The [Gator Base](#) must be 6" (15 cm) wider on all sides than the paved area.
- STEP 3 When using **GATOR BASE SCREWS**, install one screw at every second hole and every junction of the edges to ensure continuous lateral support.



Packaging:	Product	Units per Package	Package per Box
	<b>Gator Base Screws</b>	1/8 LD HOLLOW ANCHOR (50 UNITS)	20



**Alliance Designer Products Inc.**  
 1800 Berlier st. suite 200, Laval, Quebec, Canada H7L 4S4  
 Tel.: 450 624-1611 Fax : 450 624-1622 Toll free : 1 866-212-1611  
 www.alliancegator.com - Email : info@alliancegator.com